

■ Lista de Códigos das Marcas ■

RC-22AC

Nome da Marca	Botão	Código para configuração	Modo				Sentido		Força		Timer		
			Frio	Quente	Seco	Auto	Vertical	Horiz	ON	OFF	ON	OFF	
DAIKIN	[冷房]	01,02,04,05	○	○	○	○	○	○	○	○	○	○	
		03	○	○	○	○	○	○	○	○	○	○	
		06	○	○	○	○	○	○	○	○	○	○	
		09	○	○	○	○	○	○	○	○	○	○	
		08,11,12	○	○	○	○	○	○	○	○	○	○	
		45	○	○	○	○	○	○	○	○	○	○	
		07	○	○	○	○	○	○	○	○	○	○	
		10,13,15	○	○	○	○	○	○	○	○	○	○	
		23,27,29,31,39,41,43,44	○	○	○	○	○	○	○	○	○	○	
		19,21,33	○	○	○	○	○	○	○	○	○	○	
SHARP	[冷房] Ar-Frio	25	○	○	○	○	○	○	○	○	○		
		17,37	○	○	○	○	○	○	○	○	○		
		35	○	○	○	○	○	○	○	○	○		
		14,16	○	○	○	○	○	○	○	○	○		
		24,28,30,32,40,42	○	○	○	○	○	○	○	○	○		
		20,22,34	○	○	○	○	○	○	○	○	○		
		26	○	○	○	○	○	○	○	○	○		
		18,38	○	○	○	○	○	○	○	○	○		
		36	○	○	○	○	○	○	○	○	○		
		47	○	○	○	○	○	○	○	○	○		
CHOFU	[冷房] Ar-Frio	46	○	○	○	○	○	○	○	○	○		
		03,07	○	○	○	○	○	○	○	○	○		
		02,04,06	○	○	○	○	○	○	○	○	○		
		05	○	○	○	○	○	○	○	○	○		
		01	○	○	○	○	○	○	○	○	○		
		08,14,18	○	○	○	○	○	○	○	○	○		
		11,12,19,20	○	○	○	○	○	○	○	○	○		
		13,15,17,22	○	○	○	○	○	○	○	○	○		
		10	○	○	○	○	○	○	○	○	○		
		09	○	○	○	○	○	○	○	○	○		
SHARP	[暖房] Ar-Quente	16	○	○	○	○	○	○	○	○	○		
		21	○	○	○	○	○	○	○	○	○		
		30	○	○	○	○	○	○	○	○	○		
		23,24,25,26,29	○	○	○	○	○	○	○	○	○		
		28	○	○	○	○	○	○	○	○	○		
		27	○	○	○	○	○	○	○	○	○		
		01,02,04	○	○	○	○	○	○	○	○	○		
		08,09,10	○	○	○	○	○	○	○	○	○		
		06,07	○	○	○	○	○	○	○	○	○		
		05	○	○	○	○	○	○	○	○	○		
CORONA	[除湿] Ar-Seco	03	○	○	○	○	○	○	○	○	○		
		11,13,14,17	○	○	○	○	○	○	○	○	○		
		18	○	○	○	○	○	○	○	○	○		
		15	○	○	○	○	○	○	○	○	○		
		16	○	○	○	○	○	○	○	○	○		
		12	○	○	○	○	○	○	○	○	○		
		27	○	○	○	○	○	○	○	○	○		
		19,20,21,22,23,24,25,28	○	○	○	○	○	○	○	○	○		
		26	○	○	○	○	○	○	○	○	○		
		29	○	○	○	○	○	○	○	○	○		
FUJITSU	[除湿] Ar-Seco	30	○	○	○	○	○	○	○	○	○		
		31	○	○	○	○	○	○	○	○	○		
		08	○	○	○	○	○	○	○	○	○		
		06,011,15,16,17	○	○	○	○	○	○	○	○	○		
		07,13	○	○	○	○	○	○	○	○	○		
		02,04,05,09,10	○	○	○	○	○	○	○	○	○		
		01,03	○	○	○	○	○	○	○	○	○		
		18,19,20	○	○	○	○	○	○	○	○	○		
		14	○	○	○	○	○	○	○	○	○		
		12	○	○	○	○	○	○	○	○	○		
SHARP	[自動] Automático	27,29,31	○	○	○	○	○	○	○	○	○		
		21,22,24,25,28,30	○	○	○	○	○	○	○	○	○		
		32	○	○	○	○	○	○	○	○	○		
		23,26	○	○	○	○	○	○	○	○	○		
		33	○	○	○	○	○	○	○	○	○		
		MITSUBISHI (BEAVER)	[自動] Automático	08	○	○	○	○	○	○	○	○	○
				02,04,05,09,10	○	○	○	○	○	○	○	○	○
				07,13	○	○	○	○	○	○	○	○	○
				01,03	○	○	○	○	○	○	○	○	○
				18,19,20	○	○	○	○	○	○	○	○	○
12	○			○	○	○	○	○	○	○	○		
27,29,31	○			○	○	○	○	○	○	○	○		
21,22,24,25,28,30	○			○	○	○	○	○	○	○	○		
32	○			○	○	○	○	○	○	○	○		
23,26	○			○	○	○	○	○	○	○	○		

OAR-N9/OAR-N12

Nome da Marca	Botão	Código para configuração	Modo				Sentido		Força		Timer		
			Frio	Quente	Seco	Auto	Vertical	Horiz	ON	OFF	ON	OFF	
DAIKIN	[冷房] Ar-Seco	01	○	○	○	○	○	○	○	○	○	○	
		02,04,06	○	○	○	○	○	○	○	○	○	○	
		03,07	○	○	○	○	○	○	○	○	○	○	
		05	○	○	○	○	○	○	○	○	○	○	
		08,14,18	○	○	○	○	○	○	○	○	○	○	
		09	○	○	○	○	○	○	○	○	○	○	
		10	○	○	○	○	○	○	○	○	○	○	
		11,12,19,20,31	○	○	○	○	○	○	○	○	○	○	
		13,15,17,22	○	○	○	○	○	○	○	○	○	○	
		16	○	○	○	○	○	○	○	○	○	○	
SHARP	[冷房] Ar-Seco	21	○	○	○	○	○	○	○	○	○		
		23,24,25,26,29	○	○	○	○	○	○	○	○	○		
		27	○	○	○	○	○	○	○	○	○		
		28	○	○	○	○	○	○	○	○	○		
		30	○	○	○	○	○	○	○	○	○		
		01,03	○	○	○	○	○	○	○	○	○		
		02,04,05,09,10	○	○	○	○	○	○	○	○	○		
		06,11,15,16,17	○	○	○	○	○	○	○	○	○		
		07,13	○	○	○	○	○	○	○	○	○		
		08	○	○	○	○	○	○	○	○	○		
MITSUBISHI	[冷房] Ar-Frio	14	○	○	○	○	○	○	○	○	○		
		18,19,20	○	○	○	○	○	○	○	○	○		
		21,22,24,25,28,30	○	○	○	○	○	○	○	○	○		
		23,26	○	○	○	○	○	○	○	○	○		
		27,29,31	○	○	○	○	○	○	○	○	○		
		32	○	○	○	○	○	○	○	○	○		
		33	○	○	○	○	○	○	○	○	○		
		SHARP	[暖房] Ar-Quente	01,02,04,05	○	○	○	○	○	○	○	○	○
				03,07	○	○	○	○	○	○	○	○	○
				06	○	○	○	○	○	○	○	○	○
09	○			○	○	○	○	○	○	○	○		
10,13,14	○			○	○	○	○	○	○	○	○		
11	○			○	○	○	○	○	○	○	○		
12,15,17	○			○	○	○	○	○	○	○	○		
16,18	○			○	○	○	○	○	○	○	○		
19,39	○			○	○	○	○	○	○	○	○		
20,40	○			○	○	○	○	○	○	○	○		
SHARP	[暖房] Ar-Quente	21,23,35	○	○	○	○	○	○	○	○	○		
		22,24,36	○	○	○	○	○	○	○	○	○		
		25,29,31,33,41,43,45,46	○	○	○	○	○	○	○	○	○		
		26,30,32,34,42,44	○	○	○	○	○	○	○	○	○		
		27	○	○	○	○	○	○	○	○	○		
		28	○	○	○	○	○	○	○	○	○		
		37	○	○	○	○	○	○	○	○	○		
		47	○	○	○	○	○	○	○	○	○		
		48	○	○	○	○	○	○	○	○	○		
		49	○	○	○	○	○	○	○	○	○		
TOSHIBA	[自動] Automático	01,02,04	○	○	○	○	○	○	○	○	○		
		03	○	○	○	○	○	○	○	○	○		
		06	○	○	○	○	○	○	○	○	○		
		06,07	○	○	○	○	○	○	○	○	○		
		08,09,10	○	○	○	○	○	○	○	○	○		
		11,13,14,17	○	○	○	○	○	○	○	○	○		
		12	○	○	○	○	○	○	○	○	○		
		15	○	○	○	○	○	○	○	○	○		
		18	○	○	○	○	○	○	○	○	○		
		19,20,21,22,23,24,25,28	○	○	○	○	○	○	○	○	○		
FUJITSU	[自動] Automático	26	○	○	○	○	○	○	○	○	○		
		27	○	○	○	○	○	○	○	○	○		
		29	○	○	○	○	○	○	○	○	○		
		30	○	○	○	○	○	○	○	○	○		
		31	○	○	○	○	○	○	○	○	○		
		08	○	○	○	○	○	○	○	○	○		
		06,011,15,16,17	○	○	○	○	○	○	○	○	○		
		07,13	○	○	○	○	○	○	○	○	○		
		02,04,05,09,10	○	○	○	○	○	○	○	○	○		
		01,03	○	○	○	○	○	○	○	○	○		
SHARP	[自動] Automático	18,19,20	○	○	○	○	○	○	○	○	○		
		12	○	○	○	○	○	○	○	○	○		
		27,29,31	○	○	○	○	○	○	○	○	○		
		21,22,24,25,28,30	○	○	○	○	○	○	○	○	○		
		32	○	○	○	○	○	○	○	○	○		
		23,26	○	○	○	○	○	○	○	○	○		
		33	○	○	○	○	○	○	○	○	○		
		MITSUBISHI (BEAVER)	[自動] Automático	08	○	○	○	○	○	○	○	○	○
				02,04,05,09,10	○	○	○	○	○	○	○	○	○
				07,13	○	○	○	○	○				

RC-34AC

Nome da Marca	Botão	Código para configuração	Modo				Sentido		Força
			Frio	Quente	Seco	Auto	Vertic	Horiz	
DAIKIN	[不明]	01,07	○	○	○	○	○	○	○
		02,03,04,05,06	○	○	○	○	○	○	○
		08	○	○	○	○	○	○	○
SHARP	Ar-Frio	09	○	○	○	○	○	○	○
		10,12	○	○	○	○	○	○	○
		11,18,24,26	○	○	○	○	○	○	○
		13,15,16	○	○	○	○	○	○	○
		14,17	○	○	○	○	○	○	○
CHOFU	[不明]	19,20,21,22,23,25,27	○	○	○	○	○	○	○
		28,29,31,32	○	○	○	○	○	○	○
		30	○	○	○	○	○	○	○
PANASONIC	[不明]	01,02,05,06	○	○	○	○	○	○	○
		03,04,07	○	○	○	○	○	○	○
		08	○	○	○	○	○	○	○
		09	○	○	○	○	○	○	○
SANYO	Ar-Quente	10,11,12,19	○	○	○	○	○	○	○
		16	○	○	○	○	○	○	○
		17,18,20,21,22,24,25,26,2	○	○	○	○	○	○	○
		13,14	○	○	○	○	○	○	○
		15	○	○	○	○	○	○	○
		23	○	○	○	○	○	○	○
		28	○	○	○	○	○	○	○
HITACHI	[不明]	29,33	○	○	○	○	○	○	○
		30,31,32	○	○	○	○	○	○	○
TOSHIBA	[不明]	02,05	○	○	○	○	○	○	○
		01,03,04,06,07,08	○	○	○	○	○	○	○
		09	○	○	○	○	○	○	○
CORONA	[除濕]	10	○	○	○	○	○	○	○
		11,12,15	○	○	○	○	○	○	○
		13,14,16	○	○	○	○	○	○	○
		17	○	○	○	○	○	○	○
FUJITSU	[除濕]	18,19,20,21,22,23,24,25,2	○	○	○	○	○	○	○
		27	○	○	○	○	○	○	○
FUNAI	[除濕]	28	○	○	○	○	○	○	○
		L G電子	○	○	○	○	○	○	○
MITSUBISHI	[自動]	01,02,03,05,06	○	○	○	○	○	○	○
		04,07,10	○	○	○	○	○	○	○
		08,11	○	○	○	○	○	○	○
MITSUBISHI	Automático	09,12	○	○	○	○	○	○	○
		13,14,15,16,17,18,19,20	○	○	○	○	○	○	○
		21,22,25	○	○	○	○	○	○	○
		23,24	○	○	○	○	○	○	○
MITSUBISHI	[自動]	26	○	○	○	○	○	○	○
		26	○	○	○	○	○	○	○

RC-38AC-LE

Nome da Marca	Modo	Código para configuração
DAIKIN	冷房 Ar-Frio	01,02,03,04,05,06,07,08,09,10,11,12
シャープ (SHARP)	冷房 Ar-Frio	13,14,15,16,17,18,19,20,21,22,23,24,25,26,27,28
長府 (CHOFU)	冷房 Ar-Frio	33,34,35,36,37
パナソニック(National)	暖房 Ar-Quente	01,02,03,04,05,06,07,08,09,10,11,12
三洋 (SANYO)	暖房 Ar-Quente	13,14,15,16,17,18,19,20,21,22,23,24,25,26,27,28
日立 (HITACHI)	暖房 Ar-Quente	32,33,34,35,36,37,38
東芝 (TOSHIBA)	除湿 Ar-Seco	01,02,03,04,05,06,07,08,09,10,11,12,13,14,15,16,17
コロナ (CORONA)	除湿 Ar-Seco	18,19,20,21,22,23,24,25
富士通 (FUJITSU)	除湿 Ar-Seco	26,27,28,29,30,31,32,33,34,35,36,37
フナイ(FUNAI)	除湿 Ar-Seco	38,39,40
LG電子	除湿 Ar-Seco	41,42,43
アイリスオーヤマ	除湿 Ar-Seco	26,44
三菱 (MITSUBISHI)	自動 Automático	01,02,03,04,05,06,07,08,09,10,11,12,13,14,15,16
三菱 (MITSUBISHI General)	自動 Automático	21,22,23,24,25,26,27,28,29,30,31,32,33,34,35
フィフティ	自動 Automático	26,36

UMA-ACRM02

Nome da Marca	Código para configuração
長府 (CHOFU)	835~838, 874, 907
コロナ (CORONA)	760~769
ダイキン (DAIKIN)	740~759
富士通 (FUJITSU)	257, 700~719
フナイ(FUNAI)	246, 248, 258, 267
日立 (HITACHI)	640~659
LG電子	600~609
三菱 (MITSUBISHI)	551~559, 909
NEC	500~550, 860, 943, 946
パナソニック(National)	660~689, 902, 970
三洋 (SANYO)	500~550, 860, 943, 946
シャープ (SHARP)	249, 917, 720~739
東芝 (TOSHIBA)	630~639

EL1901

三洋 (SANYO)	500~550, 840~841, 869~871, 873, 876, 823, 916, 920, 924, 959, 860, 943, 946	三菱 (MITSUBISHI)	551~559, 909, 972
長府 (CHOFU)	835~838, 874, 907	パナソニック (Panasonic)	660~689, 902, 970
コロナ (CORONA)	760~769	シャープ (Sharp)	249, 720~739, 917
ダイキン (DAIKIN)	740~759	東芝 (TOSHIBA)	630~639
富士通 (FUJITSU)	700~719, 257, 634, 659, 950, 966	SAMSUNG	610~629
日立 (HITACHI)	640~659	NEC	500~550, 860, 943, 946
LG	600~609		

ACR-300YD

Fabricante	Modo	Código para configuração	Modo				Sentido		Força	Timer
			Frio	Quente	Seco	Auto	Vertic	Horiz		
TOSHIBA	Ar seco	01, 02, 04	○	○	○	○	○	○	ON	OFF
		08, 09, 10	○	○	○	○	○	○	○	○
		06, 07	○	○	○	○	○	○	○	○
		05	○	○	○	○	○	○	○	○
		03	○	○	○	○	○	○	○	○
Corona	Ar seco	11, 13, 14, 17	○	○	○	○	○	○	○	○
		18	○	○	○	○	○	○	○	○
		15	○	○	○	○	○	○	○	○
		16	○	○	○	○	○	○	○	○
		12	○	○	○	○	○	○	○	○
Fujitsu General	Ar seco	27	○	○	○	○	○	○	○	○
		19, 20, 21, 22, 23, 24, 25,	○	○	○	○	○	○	○	○
		26	○	○	○	○	○	○	○	○
Funai	Ar seco	29	○	○	○	○	○	○	○	○
		30	○	○	○	○	○	○	○	○
LG	Ar seco	31	○	○	○	○	○	○	○	
Mitsubishi	Auto	08	○	○	○	○	○	○	○	○
		06, 11, 15, 16, 17	○	○	○	○	○	○	○	○
		07, 13	○	○	○	○	○	○	○	○
		02, 04, 05, 09, 10	○	○	○	○	○	○	○	○
		01, 03	○	○	○	○	○	○	○	○
		18, 19, 20	○	○	○	○	○	○	○	○
		14	○	○	○	○	○	○	○	○
12	○	○	○	○	○	○	○	○		
Mitsubishi MHI (Beaver)	Auto	27, 29, 31	○	○	○	○	○	○	○	○
		21, 22, 24, 25, 28, 30	○	○	○	○	○	○	○	○
		32	○	○	○	○	○	○	○	○
		23, 26	○	○	○	○	○	○	○	○
		33	○	○	○	○	○	○	○	○
Fifty (Forest Life)	Auto	33, 34	○	○	○	○	○	○	○	
DAIKIN	Frio	01, 02, 04, 05	○	○	○	○	○	○	○	○
		03	○	○	○	○	○	○	○	○
		06	○	○	○	○	○	○	○	○
		48	○	○	○	○	○	○	○	○
SHARP	Frio	09	○	○	○	○	○	○	○	○
		08, 11, 12	○	○	○	○	○	○	○	○
		45	○	○	○	○	○	○	○	○
		07	○	○	○	○	○	○	○	○
		10, 13, 15	○	○	○	○	○	○	○	○
		23, 27, 29, 31, 39, 41, 43,	○	○	○	○	○	○	○	○
		19, 21, 33	○	○	○	○	○	○	○	○
		25	○	○	○	○	○	○	○	○
		17, 37	○	○	○	○	○	○	○	○
		35	○	○	○	○	○	○	○	○
CHOFU	Frio	14, 16	○	○	○	○	○	○	○	○
		24, 28, 30, 32, 40, 42	○	○	○	○	○	○	○	○
		20, 22, 34	○	○	○	○	○	○	○	○
		26	○	○	○	○	○	○	○	○
		18, 38	○	○	○	○	○	○	○	○
Panasonic (National)	Quente	47	○	○	○	○	○	○	○	○
		46	○	○	○	○	○	○	○	○
		03, 07	○	○	○	○	○	○	○	○
SANYO	Quente	02, 04, 06	○	○	○	○	○	○	○	○
		05	○	○	○	○	○	○	○	○
		01	○	○	○	○	○	○	○	○
		08, 14, 18	○	○	○	○	○	○	○	○
		11, 12, 19, 20	○	○	○	○	○	○	○	○
HITACHI	Quente	13, 15, 17, 22	○	○	○	○	○	○	○	○
		10	○	○	○	○	○	○	○	○
		09	○	○	○	○	○	○	○	○
		16	○	○	○	○	○	○	○	○
		21	○	○	○	○	○	○	○	○
		31	○	○	○	○	○	○	○	○
		30	○	○	○	○	○	○	○	○
HITACHI	Quente	23, 24, 25, 26, 29	○	○	○	○	○	○	○	○
		28	○	○	○	○	○	○	○	○
		27	○	○	○	○	○	○	○	○

OAR-250N

Fabricante	Modo	Código para configuração
Mitsubishi MHI(Beaver)	Auto	01~14
Chofu	Auto	15~19
Corona	Auto	20~27
Fujitsu	Frio	01~09
DAIKIN	Frio	10~19
LG	Frio	20~22
Funai	Frio	23~25
HITACHI	Quente	01~09
Mitsubishi Electric	Quente	10~25
TOSHIBA	Quente	26~41
Panasonic(National)	Ar seco	01~12
SANYO	Ar seco	13~31
SHARP	Ar seco	32~49

OAR-N13

Fabricante	Modo	Código para configuração
Panasonic (National)	Ar seco	01, 02, 03, 04, 05, 06, 07, 08, 09
SANYO	Ar seco	10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
HITACHI	Ar seco	29, 30